Addendum
For DeskMate® II
Cat. No. 25-1051

Running Another Application With DeskMate II

As you become familiar with DeskMate II, you may find it convenient to use its task-switching feature. This feature permits you to switch back and forth between DeskMate II and another software package, each in a separate area of your computer's memory.

Whenever it is feasible, run your secondary application (the application to which you are switching) in text mode rather than in graphic mode. For some applications running in graphic mode, it is not possible to switch tasks successfully from DeskMate II to the secondary application.

If you attempt such a switch and you encounter unexpected results, exit the secondary application if possible. Type **exit** [ENTER] at the system prompt to close the secondary memory partition and return to DeskMate II.

If you are unable to exit the secondary application, switch back to DeskMate II, and return to the Main Menu. Then, reboot your system.

Video Boards

DeskMate II does not provide support for an external video board.

Manual Changes

Make the following changes to the DeskMate portion of your manual, *A Practical Guide to the Tandy 1000 SX.*

Page C-78 Replace Step 6 with the following:

Press [F4] for Send, and then type ^C to tell Telecom to start the communication process with the service. (Type [SHIFT] [6] to produce ^.) The correct entry appears in the figure on page C-79.

Page C-164 Disregard the reference on this page to the Cancel Mode. This mode is not required for any modems supported by DeskMate.

Page C-168 In the description of Terminal mode functions, make the following change for the **Recv** function:

Execute the Recv function as indicated. Note, however, that DeskMate does not enable you to receive a file containing binary data. Disregard the note discussing such transmission.